

SPARE PARTS LIST

PART NUMBER	ITEM DESCRIPTION	QT'Y ASSEM.	UNIT LIST PRICE (\$)
1	22101-B Base Plate	1	37.40
2	22102-B Latch Bracket Assembly	1	16.00
3	22103-A Extender, (Optional) (10" Long)	1	22.00
4	22104-B Outer Leg, Assembly Including: 9, 14, 19, & 20	4	19.25
5	22105 Inner Leg, Assembly Including: 10 & 12	4	8.20
6	22106-B Channel Bracket, Outer Leg	4	1.35
7	22107-A Tie Bracket, Outer Leg	2	1.55
8	22108 Stop Lever, Assembly	1	0.80
9	24309 Cover Plate	4	0.35
10	22110 Plate Spring, Leg Adjustment	4	1.10
11	22111 Adjusting Nut, Stop Lever Assembly	1	0.45
12	24326 Black Cap, Inner Leg	4	0.70
13	22113 Red Cap, Stop Lever	1	0.25
14	22114-B Round Head Screw	8	0.15
15	22115 Spring, Stop Lever Assembly	1	0.25
16	22116 Spacer Washer, Outer Leg	8	0.35
17	22117 Hex Bolt, Outer Leg Tie Bracket	4	0.55
18	22118 Hex Lock Nut, Outer Leg Tie Bracket	4	0.25
19	22119-B Step Lever	4	1.55
20	22120-B Extension Spring	4	0.45
21	22121 Hex Bolt, Latch Bracket Assembly	1	1.35
22	22122 Washer, Latch Bracket Assembly	1	0.15
23	22123 Round Head Screw, Stop Lever Adjustment	1	0.15
24	22130 Hex Bolt, Latch Bracket And Extender	1	0.25
25	22131 Hex Lock Nut, Latch Bracket And Extender	1	0.15
26	22132 Washer, Latch Bracket And Extender	2	0.15

